



Rev 6: rework burn-in power connector;
 add fuse between connector and regulator;
 add 5 components at pin 142 - VGN line of
 AMT3 with signal return at pin 143 (VSS-TDC);
 add Weizmann Institute to silkscreen; add
 schottky diode and resistor to reset line, remove
 1N914.

| | | | |
|--------|---------------------------|-------|--------|
| MDT436 | | | |
| File | MDT436 | | |
| Doc ID | Document Number <Doc> | | |
| Date | Wednesday, April 23, 2003 | Sheet | 1 of 1 |